Modbus-IDA

# General MODBUS TCP Master Driver

1	General MODBUS TCP Master Driver	
2	System Configuration	4
3	External Device Selection	6
4	Communication Setting	7
5	Setup Items	13
6	Supported Device	23
7	Device Code and Address Code	26
8	Error Messages	27

#### Introduction

This manual describes how to connect the Display and the External Device (target PLC).

In this manual, the connection procedure will be described in the sections identified below.



# 1 General MODBUS TCP Master Driver

The general MODBUS TCP Master Driver is used to connect the Display to a MODBUS-compatible External Device for general purpose.

The function code and boundary required for communication can be changed according to the External Device.

# 2 System Configuration

The system configuration in the case when the External Device and the Display are connected is shown.

Series	CPU	Link I/F	SIO Type	Setting Example
MODBUS Slave Devi	ce <sup>*1</sup>		Ethernet (TCP)	Setting Example 1 (page 7)

\*1 To connect with External Device using the Modbus protocol, configure the [Device Setting] to match the specifications on the External Device.

Setup Items (page 13)

External Device used to confirm connection

Series	CPU	Link I/F	SIO Type	Setting Example
Hitachi Indus- trial Equipment	MVH-A64		Ethernet (TCP) Setting Examp (page 9)	
Systems Co., Ltd. MICRO-EHV	MVH-A40	Ethernet port on basic unit	Ethernet (TCP) (Modbus Gateway)	Setting Example 3 (page 11)

## Connection Configuration

1:1 Connection



1: n Connection



### ♦ n: 1 Connection

The number of connectable Displays depends on the External Device.



# 3 External Device Selection

Select the External Device to be connected to the Display.

💰 Welcome to GP-Pro EX		x
GP-Pro 🛃	Device/PLC	ices/PLCs
Image: Series General MODBUS TCP Master         Port       Ethernet (TCP)         Refer to the manual of this Device/PLC         Image: System Area             Device Information		
	X       X         Device/PLC       1         Number of Devices/PLCs       1         Device/PLC       1         Manufacturer       Modbus-IDA         Series       General MODBUS TCP Master         Port       Ethernet (TCP)         Refer to the manual of this Device/PLC         Recent Device/PLC         Image: Use System Area         Device Information	
	Port	Ethernet (TCP)
	Device/PLC         Number of Devices/PLCs         Device/PLC1         Manufacturer         ModbustDA         Series         General MODBUS TCP Master         Pott         Ethernet (TCP)         Refer to the manual of this Device/PLC         Recent Device/PLC         Image: Comparison of the system Area	
		Recent Device/PLC
	1	>
	Use System	Area Device Information
	Back (E	Communication Settings New Logic New Screen Cancel

Setup Items	Setup Description		
Number of Devices/ PLCs	Enter an integer from 1 to 4 to define the number of Devices/PLCs to connect to the display.		
Manufacturer	Select the manufacturer of the External Device to connect. Select "Modbus-IDA".		
Series	Select the External Device model (series) and the connection method. Select "General MODBUS TCP Master". In System configuration, make sure the External Device you are connecting is supported by "General MODBUS TCP Master".		
Port	Select the Display port to connect to the External Device.		
Use System Area	Check this option to synchronize the system data area of the Display and the device (memory) of the External Device. When synchronized, you can use the External Device's ladder program to switch the display or display the window on the Display. Cf. GP-Pro EX Reference Manual "LS Area (Direct Access Method Area)" This feature can also be set in GP-Pro EX or in the Display's offline mode. Cf. GP-Pro EX Reference Manual "System Settings [Display Unit] - [System Area] Settings Guide" Cf. Maintenance/Troubleshooting Guide "Main Unit - System Area Settings"		

# 4 Communication Setting

Examples of communication settings of the Display and the External Device, recommended by Pro-face, are shown.

## 4.1 Setting Example 1

- GP-Pro EX Settings
- Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].

Device/PLC 1	
Summary	Change Device/PLC
Manufacturer Modbus-IDA Series General MODBUS TCP Master	Port Ethernet (TCP)
Text Data Mode 1 Change	
Communication Settings	
Port No. 1024 😴 🗹 Auto	
Timeout 3 😴 (sec)	
Retry 0	
Wait To Send 0 🛫 (ms) Default	
Device-Specific Settings	
Allowable Number <u>Add Device</u> of Devices/PLCs 16	
No. Device Name Settings	Add Indirect Device
1 PLC1 IP Address=192.168.000.001,Port No.=502,Unit ID=25	<b></b>

#### Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

quipment Configuration Funct	ion Code and Max Query
Equipment Address	
IP Address	192. 168. 0. 1
Port No.	502 🕂
Unit ID	255
Bit manipulation (set/reset) to H	Holding Register
Rest of the bits in this word	C Clear       O Do not clear
Note on when selecting "Do If the ladder program writes process, the resulting data	on ot clear" : data to Holding Register during the read/write may be incorrect
EC61131 Syntax	
☐ IEC61131 Syntax — Address Mode	O-based (Default)
☐ IEC61131 Syntax Address Mode If you change the setting, ple	D-based (Default)
IEC61131 Syntax     Address Mode      If you change the setting, ple Variables	(Jbased (Default) y ase reconfirm all address settings.
LEC61131 Syntax Address Mode If you change the setting, ple Variables Double Word word order	Observed (Default)     Y       ase reconfirm all address settings.       Low word first(L/H)

[Equipment Configuration] Tab

[Function	Code	and	Max	Query]	Tab
-----------	------	-----	-----	--------	-----

Individual Device	e Settings				
LC1					
Equipment Configur	ation Function	n Code and M	dax Query		
Auto adjust to fr	ame length	0.0	Tustom		
<ul> <li>Auto adjust to n</li> </ul>	ane lengtri		Justom		
Frame Length	258				
Start Address	Range	Read	Boundary	Write	Boundary
000001	65536	01	2000	OF	800
100001	65536	02	2000		
300001	65536	04	125		100
400001	60036	03	125	10	100
mport Export					Default
				OK ( <u>O</u> )	Cancel

#### Notes

- Check with your network administrator about the IP address you want to use.
- Do not duplicate IP addresses on the same network.
- In [Individual Device Settings], set the IP address of the External Device.
- Set the Display's IP address in offline mode.

### External Device Settings

External Device settings vary depending on the device. Refer to your External Device manual for details.

#### Notes

- · Check with your network administrator about the IP address you want to use.
- Do not duplicate IP addresses on the same network.

## 4.2 Setting Example 2

- GP-Pro EX Settings
- Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].

Device/PLC 1		
Summary		Change Device/PLC
Manufacturer Modb	us-IDA Series General MODBUS TCP Master	Port Ethernet (TCP)
Text Data Mode	1 Change	
Communication Settings		
Port No.	1024 📑 🔽 Auto	
Timeout	3 :: (sec)	
Retry	0 🕂	
Wait To Send	0 📑 (ms) Default	
Device-Specific Settings		
Allowable Number of Devices/PLCs	Add Device 16	Addle for a
No. Device Name	Settings	Add Indirect Device
👗 1 🛛 PLC1	IP Address=192.168.000.001,Port No.=502,Unit ID=25	<b>+</b>

#### Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

#### [Equipment Configuration] Tab

💰 Individual Device Settings		×
PLC1		
Equipment Configuration Functi	ion Code and Max Query ]	
IP Address	192. 168. 0. 1	
Port No.	502	
Unit ID	255	
Bit manipulation (set/reset) to H	Iolding Register	
Rest of the bits in this word	C Clear	
Note on when selecting "Do If the ladder program writes process, the resulting data m	not clear" : data to Holding Register during the read/write nay be incorrect.	
EC61131 Syntax		
Address Mode	0-based (Default)	
If you change the setting, plea	ase reconfirm all address settings.	
Variables		
Double Word word order	Low word first(L/H)	
Import Export	Default	
	OK ( <u>D</u> ) Cancel	

#### [Function Code and Max Query] Tab

Individual Device PLC1 Equipment Configuration Auto adjust to fr	Settings ation Function ame length	n Code and M	Max Query   Custom		ľ
Frame Length Start Address 000001 100001 300001 400001	258 65536 65536 65536 65536 65536	Read 01 02 04 03	Boundary 2000 2000 125 125	Write OF  10	Boundary 800  100
Import Export				OK ( <u>D)</u>	Default Cancel

#### Notes

- Check with your network administrator about the IP address you want to use.
- Do not duplicate IP addresses on the same network.
- In [Individual Device Settings], set the IP address of the External Device.
- Set the Display's IP address in offline mode.

## External Device Settings (Ethernet port on basic unit)

Use the programming software (Control Editor) for communication settings. Please refer to the manual of the External Device for more details.

## Procedure

- 1. Start the programming software and create a project. The project appears in offline mode.
- 2. In the tree view, from [CPU Parameters] double-click [CPU settings] and [IP address]. The [CPU Communication Setting (IP Address)] dialog box appears.
- 3. Set the following items and click [Set].

Setup Items	Setting
IP Address	192.168.0.1
Subnet mask	255.255.255.0
Default gateway	0.0.0.0
Link Speed / Duplex	Auto Negotiation

- 4. In the tree view, from [CPU Parameters] double-click [CPU settings] and [Modbus-TCP/RTU]. The [CPU communication settings (Modbus-TCP/RTU)] dialog box appears.
- 5. Set the following items and click [Set].

Setup Items	Setting	Remarks
Port No.	502	
Enable gateway	OFF	
Ethernet timeout	3000	Set to 0 when not using timeout.

- 6. Enter online mode, and transfer the settings to the External Device.
- 7. Restart the External Device.

### Notes

• Check with your network administrator about the IP address you want to use. Do not duplicate IP addresses on the same network.

## 4.3 Setting Example 3

- GP-Pro EX Settings
- Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].

Device/PLC 1		
Summary		Change Device/PLC
Manufacturer Modb	us-IDA Series General MODBUS TCP Master	Port Ethernet (TCP)
Text Data Mode	1 Change	
Communication Settings		
Port No.	1024 📑 🔽 Auto	
Timeout	3 📫 (sec)	
Retry	0 📑	
Wait To Send	0 🕂 (ms) Default	
Device-Specific Settings		
Allowable Number of Devices/PLCs	Add Device 16	
No. Device Name	Settings	Add Indirect Device
👗 1 🛛 PLC1	IP Address=192.168.000.001,Port No.=502,Unit ID=25	<b>+</b>

#### Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings]

To connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

#### [Equipment Configuration] Tab

💰 Individual Device Settings		×
PLC1		
Equipment Configuration Functi	ion Code and Max Query ]	
IP Address	192. 168. 0. 1	
Port No.	502	
Unit ID	255	
Bit manipulation (set/reset) to H	Iolding Register	
Rest of the bits in this word	C Clear	
Note on when selecting "Do If the ladder program writes process, the resulting data m	not clear" : data to Holding Register during the read/write nay be incorrect.	
EC61131 Syntax		
Address Mode	0-based (Default)	
If you change the setting, plea	ase reconfirm all address settings.	
Variables		
Double Word word order	Low word first(L/H)	
Import Export	Default	
	OK ( <u>D</u> ) Cancel	

#### [Function Code and Max Query] Tab

Individual Device PLC1     Equipment Configura     O Auto adjust to fr	Settings ation Function ame length	n Code and I	Max Query   Custom		2
Frame Length Start Address 000001 100001 200001 400001	258 Bange 65536 65536 65536 65536	Read 01 02 04 03	Boundary 2000 2000 125 125	Write OF  10	Boundary 800  100
Import Export				OK ( <u>D</u> )	Default

#### Notes

- Check with your network administrator about the IP address you want to use.
- Do not duplicate IP addresses on the same network.
- In [Individual Device Settings], set the IP address of the External Device.
- Set the Display's IP address in offline mode.

## External Device Settings (Ethernet port on basic unit)

Use the programming software (Control Editor) for communication settings. Please refer to the manual of the External Device for more details.

## Procedure

- 1. Start the programming software and create a project. The project appears in the offline mode.
- 2. In the tree view, from [CPU Parameters] double-click [CPU settings] and [IP address]. The [CPU Communication Setting (IP Address)] dialog box appears.
- 3. Set the following items and click [Set].

Setup Items	Setting
IP Address	192.168.0.1
Subnet mask	255.255.255.0
Default gateway	0.0.0.0
Link Speed / Duplex	Auto Negotiation

- 4. In the tree view, from [CPU Parameters] double-click [CPU settings] and [Modbus-TCP/RTU]. The [CPU communication settings (Modbus-TCP/RTU)] dialog box appears.
- 5. Set the following items and click [Set].
  - Modbus-TCP Settings

Setup Items	Setting	Remarks
Port No.	502	
Enable gateway	OFF	
Ethernet timeout	3000	Set to 0 when not using timeout.

Modbus-RTU Settings

Setup Items	Setting	Remarks
Serial com. Baudrate	115.2kbps	Match the settings of Modbus Slave devices.
Serial com. Format	8-E-1	Data length: 8-bit, Even parity, Stop bit: 1-bit Match the settings of Modbus Slave devices.
Serial com. Timeout	100	Set to 0 when not using timeout.

- 6. Enter online mode, and transfer the settings to the External Device.
- 7. Restart the External Device.

### Notes

• Check with your network administrator about the IP address you want to use. Do not duplicate IP addresses on the same network.

# 5 Setup Items

Set up the Display's communication settings in GP-Pro EX or in the Display's offline mode.

The setting of each parameter must match that of the External Device.

"4 Communication Setting" (page 7)

• Set the Display's IP address in offline mode. NOTE Cf. Maintenance/Troubleshooting Guide "Ethernet Settings"

## 5.1 Setup Items in GP-Pro EX

## Communication Settings

To display the setup screen, from the [Project] menu, point to [System Settings] and select [Device/PLC].

Device/PLC 1					
Summary				1	Change Device/PLC
Manufacturer Modbu	us-IDA	Series	General MODBUS TCP Master	Port	Ethernet (TCP)
Text Data Mode	1 Change				
Communication Settings					
Port No.	1024 😤 🗹 Auto				
Timeout	3 📫 (sec)				
Retry	0 🕂				
Wait To Send	0 📫 (ms)	Def	ault		
Device-Specific Settings					
Allowable Number of Devices/PLCs	Add Device 16				
No. Device Name	Settings			Add Dev	l Indirect rice
👗 1 🛛 PLC1	IP Address=192.	168.000.0	101,Port No.=502,Unit ID=25		<b>+</b>

Setup Items	Setup Description
Port No.	Use an integer from "1024 to 65535" to enter the port number of the Display. If you check [Auto], the port number will be automatically set.
Timeout	Use an integer from 1 to 127 to enter the time(s) for which the Display waits for the response from the External Device.
Retry	In case of no response from the External Device, enter how many times the Display retransmits the command, from "0 to 255".
Wait To Send	Enter the standby time (ms) from when the Display receives packets until it transmits the next command, from "0 to 5000".

NOTE

Refer to the GP-Pro EX Reference Manual for Indirect Device.

Cf. GP-Pro EX Reference Manual "Changing the Device/PLC at Runtime (Indirect Device)"

## Device Setting

To display the [Individual Device Settings] dialog box, from [Device-Specific Settings] in the [Device/PLC] window, select the external device and click [Settings] in the connect multiple External Devices, from [Device-Specific Settings] in the [Device/PLC] window, click [Add Device] to add another External Device.

• [Equipment Configuration] Tab

Individual Device Settings	×
PLC1	
Equipment Configuration Funct	ion Code and Max Query
Equipment Address	
IP Address	192. 168. 0. 1
Port No.	502
Unit ID	255 💌
Bit manipulation (set/reset) to H	Holding Register
Rest of the bits in this word	O Clear 💿 Do not clear
Note on when selecting "Do If the ladder program writes process, the resulting data r	o not clear" : data to Holding Register during the read/write may be incorrect.
Address Mode	O based (D-fault)
Address mode	
If you change the setting, ple	ase reconfirm all address settings.
Variables	
Double Word word order	Low word first(L/H)
Import Export	Default
	OK ( <u>D</u> ) Cancel

Setu	ip Items	Setup Description	
		Set the IP address of the External Device.	
IP Address		<ul> <li>NOTE</li> <li>Check with your network administrator about the IP address you want to use.</li> <li>Do not duplicate IP addresses on the same network.</li> </ul>	
Port No.		Use an integer from "1 to 65535" to enter the port number of the External Device.	
Unit ID		Use an integer from 1 to 247 (or 255) to enter the unit ID of the External Device.	
Bit manipulation (set/reset) to Holding Register		Select how other bits in the same word are handled when you manipulate bits in the holding register, from "Clear" or "Do not clear".	
Rest of the bits in this word			
IEC61131 Syntax		Select this item to use the IEC61131 syntax for variables. If you check this item, select the address mode from "0-based" or "1-based".	
Double Word word order		Select the order of storing double word data from "Low word first" or "High word first".	
Import		Import the device settings described in the xml file. <sup>(GP)</sup> " ◆ Import Procedure in the Device Setting" (page 18)	
Export		Export the device settings into the xml file.	

[Function Code and Max	Query] Tab (when	"Auto adjust to frame	length" is selected)
------------------------	------------------	-----------------------	----------------------

Inc PLC1	lividual Device	Settings				X
Equi	pment Configurat	ion Function	Code and Ma	ax Query		
•	Auto adjust to fra	me length	O Cu	istom		
Fra	me Length	258		*		
St 00 10 30 40	art Address 0001 0001 0001 0001	Range 65536 65536 65536 65536 65536	Read 01 02 04 03	Boundary 2000 2000 125 125	Write OF  10	Boundary 800  100
Impo	ort <u>Export</u>					Default
				0	)K ( <u>0)</u>	Cancel

Setup Items	Setup Description
Auto adjust to frame length	Automatically set each function code and the boundary for one communication according to the frame length. Function codes cannot be changed. To change a function code, use "Custom".
Frame Length	Set the frame length from "10 to 258". After setting, click the device list to display the boundary.
Import	Import the device settings described in the xml file. ☞ " ◆ Import Procedure in the Device Setting" (page 18)
Export	Export the device settings into the xml file. <sup>C</sup> " ◆ Export Procedure in the Device Setting" (page 18)

## NOTE

• When "Auto adjust to frame length" is selected, use the following function codes. The read/ write boundary is automatically calculated according to "Frame Length".

Device	Function Code		
Device	Read	Write	
Coil	01	0F: Force Multiple Coils	
Discrete Input	02	Disabled	
Input Register	04	Disabled	
Holding Register	03	10: Preset Multiple Register	

- Use "Custom" in the following cases:
  - When you use a different function code depending on an address.
  - When you use the function code "05: Force Single Coil" or "06: Preset Single Register".
  - When the read/write boundary depends on the device.

• [Function Code and Max Query] Tab (when "Custom" is selected)

💰 Individua	al Device S	ettings				×
PLC1	PLC1					
Equipment	Configuratio	on Function C	Code and Ma	x Query		
C Auto a	adjust to fran	ne length	• Du	etom.		
<ul> <li>Auto a</li> </ul>	iojust to rian	ne iengai	- Cu	stom		
Add C	Configuration	<u>Delete</u>				
Start Ad	dress	Range	Read	Boundary	Write	Boundary
000001		65536	01	2000	OF	800
100001		65536	02	2000		
300001		65536	04	125		
400001		65536	03	125	10	100
Import	Export					Default
						Cancel 1
						Sancor

Setup Items	Setup Description
Custom	Manually set each function code and the boundary for one communication.
Add	Add the function code and its data boundary settings. Up to 20 settings can be added. Add the settings in the [Add setting] dialog box.
Configuration	Change the selected device settings. Change the settings in the [Configuration setting] dialog box.
Delete	Delete the selected device settings.
Import	Import the device settings described in the xml file. ☞ " ◆ Import Procedure in the Device Setting" (page 18)
Export	Export the device settings into the xml file.

• [Add setting] Dialog Box / [Configuration setting] Dialog Box

Add setting		C
Start Address	000001	
Range	65536	
Read Function Code	01	
Boundary	2000 🕂	
Write Function Code	OF (Multiple)	
Boundary	800 🛨	
OK	Cancel	

Configuration setting		
Start Address	000001	
Range	65536	*
Read Function Code	01	
Boundary	2000	*
Write Function Code	OF (Multiple)	•
Boundary	800	÷
ОК	Cancel	

	Setup Items	Setup Description
Start Add	ress	Set the start address of the device.
Range		Set the range of the device specified in the start address.
Read		Set the function codes to be used for read and the read boundary in one communication.
	Function Code	The function code is assigned by the specified start address.
	Boundary	The boundary depends on the device. Refer to the following table for details.
Write		Set the function code to be used for write and the write boundary in one communication.
	Function Code	The function code depends on the device. Refer to the following table for details.
	Boundary	The boundary depends on the device. Refer to the following table for details.

Ν	от	Е	1

• When "Custom" is selected, use the following function codes.

	Function Code (Boundary)			
Device	Pood	Write		
	Read	Multiple	Single	
Coil	01(2000)	0F: Force Multiple Coils (800)	05: Force Single Coil (Fixed to 1)	
Discrete Input	02(2000)	Disabled	Disabled	
Input Register	04(125)	Disabled	Disabled	
Holding Register	03(125)	10: Preset Multiple Register (100)	06: Preset Single Register (Fixed to 1)	

• If the set device address is disabled to write, you cannot set the write function code and boundary.

• When you select the function code "05" or "06", the write boundary will be fixed to "1", and cannot be changed.

- Import Procedure in the Device Setting
  - 1 Create the xml file based on the following format sample.
  - Format sample when "Auto adjust to frame length" is selected

<?xml version="1.0" encoding="utf-8" ?> <ModbusConfiguration version="1"> <ClearBits>OFF</ClearBits> <AddressMode>ModiconSyntax</AddressMode> <DWORD>L/H</DWORD> <FunctionCode> <Mode>AutoAdjust</Mode> <FrameLength>258</FrameLength> </FunctionCode> </ModbusConfiguration>

Bit manipulation to Holding Register Address Mode Double Word word order

Mode Frame Length

• Format sample when "Custom" is selected

xml version="1.0" encoding="utf-8" ? <modbusconfiguration version="1"></modbusconfiguration>	
<clearbits>OFF</clearbits>	Bit manipulation to Holding Register
<addressmode>ModiconSyntax</addressmode>	Address Mode
<eunctioncode></eunctioncode>	Double word word order
<mode>Custom</mode>	Mode
<setting></setting>	
<address>000001</address>	Start Address
<range>65535</range>	Range
<read></read>	-
<functioncode>01</functioncode>	Read Function Code
<boundary>2000</boundary>	Read Boundary
<write></write>	
<functioncode>0F</functioncode>	Write Function Code
<boundary>800</boundary>	Write Boundary

2 Click [Import] on the [Individual Device Settings] dialog box to display the [Open] dialog box.

- **3** Select the created xml file and click [Open].
- ◆ Export Procedure in the Device Setting
  - 1 Click [Export] on the [Individual Device Settings] dialog box to display the [Save as] dialog box.
  - 2 Enter a name and click [Save].

## 5.2 Setup Items in Offline Mode

## NOTE

• Refer to the Maintenance/Troubleshooting guide for information on how to enter offline mode or about the operation.

- Cf. Maintenance/Troubleshooting Guide "Offline Mode"
- The number of the setup items to be displayed for 1 page in the offline mode depends on the Display in use. Please refer to the Reference manual for details.

### Communication Settings

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Settings] in offline mode. Touch the External Device you want to set from the displayed list.

Comm.	Device				-	
General MODBUS	TCP Master	 		[TCP]		Page 1/1
	Port No.	<u> </u>	ed	• Auto		
				1024 💌		
	Timeout(s) Retry	_		3 🔻		
	Wait To Send(ms)			0 🔻		
			0			
	Exit			Back	200 09	18/06/13 1:49:17

Setup Items	Setup Description
Port No.	Set the Port No. of the Display. Select either of [Fixed] or [Auto]. When you select [Fixed], use an integer from "1024 to 65535" to enter the port number of the Display.When you select [Auto], the port number will be automatically assigned regardless of the entered value.
Timeout	Use an integer from 1 to 127 to enter the time (s) for which the Display waits for the response from the External Device.
Retry	In case of no response from the External Device, enter how many times the Display retransmits the command, from "0 to 255".
Wait To Send	Enter the standby time (ms) from when the Display receives packets until it transmits the next command, from "0 to 5000".

## Device Setting

To display the setting screen, touch [Device/PLC Settings] from [Peripheral Settings]. Touch the External Device you want to set from the displayed list, and touch [Device].

(Page 1/22)



Setup Items	Setup Description
Device/PLC Name	Select the External Device to set. The device name is the title of the External Device set with GP-Pro EX.(Initial value [PLC1])
IP Address	<ul> <li>Set the IP address of the External Device.</li> <li><b>NOTE</b></li> <li>Check with your network administrator about the IP address you want to use.</li> <li>Do not duplicate IP addresses on the same network.</li> </ul>
Port No.	Use an integer from "1 to 65535" to enter the port number of the External Device.
Unit ID	Use an integer from 1 to 247 (or 255) to enter the unit ID of the External Device.
Bit manipulation to HR	Displays how other bits in the same word are handled when you manipulate bits in the holding register, as "Rest of bits in word are cleared" or "Rest of bits in word are not cleared". (Not available to set in offline mode.)
Double Word word order	Displays the currently set order of storing double word data as "Low word first" or "High word first". (Not available to set in offline mode.)
IEC61131 Syntax	Displays the usage status of the currently set IEC61131 syntax in ON/OFF. (Not available in offline mode.)

## (Page 2/22)

NOTE

Comm.	Device							.,
General MODBUS Devic	TCP Master :e/PLC Name  PL	C1		[	[TCP]		<sup>o</sup> age	2/22
	Function Code ar Auto adjust Set1 Frame Length	nd Max Quer	'y Auto a 258	adjust to	) Frame I	Length	←	→
	Exit			Ba	ack	2008	3/06/ :49:3	13 36

Setup Items	Setup Description		
Device/PLC Name	Select the External Device to set. The device name is the title of the External Device set with GP-Pro EX.(Initial value [PLC1])		
Function Code and Max Query	Displays the option to set the function code and boundary. (Not available to set in offline mode.)		
Auto adjust Setting Frame Length	Displays the set frame length when "Auto adjust to frame length" is selected in the online mode. (Not available to set in offline mode.)		

• When "Custom" is selected, the setup items of the frame length are invalid.

(Page 3/22 to 22/22)

Comm.	Device			
General MODBUS	TCP Master		[TCP]	Page 3/22
Devic	e/PLC Name  PL	C1		
	Custom Setting 1 Start Address Range Read Write	000001 65536 01 / 2 0F / 0	000 800	<b>+ +</b>
	Exit		Back	2008/06/13 09:49:45

Setup Items	Setup Description
Device/PLC Name	Select the External Device to set. The device name is the title of the External Device set with GP-Pro EX. (Initial value [PLC1])
Start Address	Displays the start address of the device. (Not available to set in offline mode.)
Range	Displays the range of the device specified in the start address. (Not available to set in offline mode.)
Read	Displays the device function codes and boundaries to be read for one communication. (Not available to set in offline mode.)
Write	Displays the device function codes and boundaries to be written for one communication. (Not available to set in offline mode.)

NOTE	• Page 3 and the following pages display the set descriptions in order.
	• When "Auto adjust to frame length" is selected, the Custom setup items are invalid.

# 6 Supported Device

Range of supported device address is shown in the table below. Please note that the actually supported range of the devices varies depending on the External Device to be used. Please check the actual range in the manual of your External Device.

## 6.1 MODBUS Slave Device

: This address can be specified as system data area.

Device	Bit Address	Word Address	32 bits	Remarks
Coil	000001 - 065536	000001 - 065521		+1B+
Discrete Input	100001 - 165536	100001 - 165521	[ <b>L/H</b> ]	( <u>+1B+</u> ) *2
Input Register		300001 - 365536	or	<b>B</b> i t <b>15</b> *2
Holding Register	400001,00 - 465536,15	400001 - 465536	[H/L]	<b>B</b> 15) <sup>*3</sup>
Input Register		D300001 - D365535	*1	<u>ві <b>1</b></u> *2
Holding Register	D400001,00 - D465535,31	D400001 - D465535		<u>₿;</u> , <b>31</b> ) *4

\*1 Whether the data is stored as higher or lower is determined by the [Double Word word order] setting in [Device Setting].

<sup>(C)</sup> "5.1 Setup Items in GP-Pro EX" (page 13)

#### \*2 Write disable.

\*3 An access method at the time of Bit Set varies depending on the [Rest of the bits in this word] setting of [Device Setting].

"Clear"......

"Do not clear"...... 400001,00 - 465536,15

\*4 An access method at the time of Bit Set varies depending on the [Rest of the bits in this word] setting of [Device Setting].

"Do not clear"...... D400001,00 - D465535,31

**NOTE** • GP-Pro EX simulation does not synchronize the coil bit address and word address values.

## ■ IEC61131 Syntax Address Description

The following table compares IEC61131 and MODBUS syntax address descriptions.

	MC	DBUS Syl	ntax		IEC61131 Syntax			
Device					0-	based	1-	based
Device	Format	Range	First element	Format	Range	First element	Range	First element
Coil	000001+i	i = 0 to 65535	000001	%Mi	i = 0 to 65535	%M00000	i = 1 to 65536	%M00001
Discrete Input	100001+i	i = 0 to 65535	100001	-	-	-	-	-
Input Register (Word)	300001+i	i = 0 to 65535	300001	-	-	-	-	-
Input Register (Word bit)	300001+i,j	i = 0 to 65535 j = 0 to 15	300001,00	-	-	-	-	-
Holding Register (Word)	400001+i	i = 0 to 65535	400001	%MWi	i = 0 to 65535	%MW00000	i = 1 to 65536	%MW00001
Holding Register (Word bit)	400001+i,j	i = 0 to 65535 j = 0 to 15	400001,00	%Mwi: Xj	i = 0 to 65535 j=0 to 15	%MW00000 :X00	i = 1 to 65536 j=0 to 15	%MW00001 :X00
Input Register (D Word)	D300001+i	i = 0 to 65534	D300001	-	-	-	-	-
Input Register (D Word bit)	D300001+i,j	i = 0 to 65534 j = 0 to 31	D300001,00	-	-	-	-	-
Holding Register (D Word)	D400001+i	i = 0 to 65534	D400001	%MDi	i = 0 to 65534	%MD00000	i = 1 to 65535	%MD00001
Holding Register (D Word bit)	D400001+i,j	i = 0 to 65534 j = 0 to 31	D400001,00	%MDi:Xj	i = 0 to 65534 j=0 to 31	%MD00000 :X00	i = 1 to 65535 j=0 to 31	%MD00001 :X00
<ul> <li>• The addresses 100000 and 300000 cannot be accessed using IEC61131 syntax.</li> <li>• If you apply IEC61131 syntax to a project that has a discrete input or input register already set, the addresses become "-Undefined-" and invalid.</li> </ul>								
<ul> <li>• Refer to the GP-Pro EX Reference Manual for system data area.</li> <li>Cf. GP-Pro EXReference Manual "LS Area (Direct Access Method Area)"</li> </ul>								

• Please refer to the precautions on manual notation for icons in the table.

"Manual Symbols and Terminology"

## 6.2 MICRO-EHV Series

: This address can be specified as system data area.

Device	Bit Address	Word Address	32 bits	Remarks
Coil	000257 - 00288	000257 - 000273		
Discrete Input	100001 - 100047	100001 - 100002		*1
Input Register		300001 - 302048		*1
Holding Register	400001.00 - 432768.15	400001 - 432768	[ <b>L/H</b> ]	
Input Register		D300001 - D302047		*1
Holding Register	D400001.00 - D432767.31	D400001 - D432767		

\*1 Write disable

If you use Control Editor's I/O Monitor to monitor Modbus devices, use the following supported addresses table when specifying addresses.

Modbus Device		External Device		
Device	Range	Device	Range	
Coil	000257 - 00288	External output	Y0100 - Y0131	
Discrete Input	100001 - 100048	External input	X0000 - X0047	
Input Register	300001 - 302048	Data area	WM000 - WM7FF	
Holding Register	400001 - 432768	Word inner output	WR0000 - WR7FFF	
Input Register	D300001 - D302047	Data area	DM000 - DM7FE	
Holding Register	D400001 - D432767	Word inner output	DR0000 - DR7FFE	

NOTE

- GP-Pro EX simulation does not synchronize the coil bit address and word address values.
- Refer to the GP-Pro EX Reference Manual for system data area.
- Cf. GP-Pro EXReference Manual "LS Area (Direct Access Method Area)"
- Please refer to the precautions on manual notation for icons in the table.
- "Manual Symbols and Terminology"

# 7 Device Code and Address Code

Use device code and address code when you set "Device Type & Address" for the address type of the data display or other devices.

Device	Device Name	Device Code (HEX)	Address Code
Coil	0	0080	Value of (word address -1) divided by 16
Discrete Input	1	0081	Value of (word address -1) divided by 16
Input Register	3	0001	Value of (word address - 1)
Holding Register	4	0000	Value of (word address - 1)
Input Register	D3	0002	Value of (word address -1) divided by 2
Holding Register	D4	0003	Value of (word address -1) divided by 2

# 8 Error Messages

Error messages are displayed on the screen of Display as follows: "No. : Device Name: Error Message (Error Occurrence Area)". Each description is shown below.

Item	Description	
No.	Error Number.	
Device Name	Name of the External Device where an error has occurred. The Device name is the title of the External Device set with GP-Pro EX.(Initial value [PLC1])	
Error Message	Displays messages related to an error that has occurred.	
	Displays the IP address or device address of the External Device where an error has occurred, or error codes received from the External Device.	
Error Occurrence Area	<ul> <li>NOTE</li> <li>IP address is displayed as "IP address (Decimal): MAC address (Hex)".</li> <li>Device address is displayed as "Address: Device address".</li> <li>Received error codes are displayed as "Decimal [Hex]".</li> </ul>	

## Display Examples of Error Messages

"RHAA035: PLC1: Error has been responded for device write command (Error Code: 2[02H])"

NOTE	Refer to your External Device manual for details on received error codes.			
	Refer to "Display-related errors" in "Maintenance/Troubleshooting Guide" for details on the			
	error messages common to the driver.			

## Error Codes Specific to the External Device

Please refer to the manual of the External Device for error codes specific to the External Device. General MODBUS error codes are shown below.

Error Code (HEX)	Description
01	Does not support the corresponding Function Code.
02	The specified data address does not exist.
03	Data value error.

## ■ Error Messages Specific to the External Device

ID	Error Message	Description
RHxx128	(Node Name): (Device Address) can't be read because of the limitation of the Read boundary	When reading the coil or discrete input as a word address while the boundary is less than 16 bits, or accessing the input or holding register as a double word while the boundary is set to 1 word, an error will be displayed.
RHxx129	(Node Name): (Device Address) can't be written because of the limitation of the Write boundary	When writing the coil as a word address while the boundary is less than 16 bits, or accessing the holding register as a double word while the boundary is set to 1 word, an error will be displayed.
RHxx130	(Node Name): (Device Address) is not defined on Function Code and Max Query setting	When accessing the device out of the defined area, an error will be displayed.
RHxx131	(Node Name): (Device Address) can't be read because of the limitation of the Device Range setting	When reading the coil or discrete input as a word address while the range is less than 16 bits, or accessing the input or holding register as a double word while the range is set to 1 word, an error will be displayed.
RHxx132	(Node Name): (Device Address) can't be written because of the limitation of the Device Range setting	When writing the coil as a word address while the range is less than 16 bits, or accessing the holding register as a double word while the range is set to 1 word, an error will be displayed.