

# Device/PLC Connection Manuals

---



## About the Device/PLC Connection Manuals

Prior to reading these manuals and setting up your device, be sure to read the "Important: Prior to reading the Device/PLC Connection manual" information. Also, be sure to download the "Preface for Trademark Rights, List of Units Supported, How to Read Manuals and Documentation Conventions" PDF file. Furthermore, be sure to keep all manual-related data in a safe, easy-to-find location.

# Matsushita Electric Industrial Connectable Devices

The following tables list the devices that can be connected and used with the GP.

## ■ PLCs

### ◆ 1:1 Connection

Series Name	CPU	Link Unit	Device type in Screen Editor	GP Series GLC 2000 Series	GLC 100 Series GLC 300 Series
Panadac 7000	P7000-PLC-001 P7000-PLC-031H P7000-PLC-031S P7000-PLC-A01	GCP001	MATSUSHITA Panadac P7000 series	○	x

## ■ Servos

Series	CPU *1	Device Type in Screen Editor
MINAS-A	M□DA□□□□□□	Matsushita Electric Industrial Co.'s MINAS-A/S Series
MINAS-S	MUDS□□□□□□	

\*1 □□□□□□ varies depending upon the servo types. For detailed information, please refer to the servo's catalog.